


BL-600_dimension_02.gif

●BL-600/601/600HA/601HA (Mounting bracket)

* Use M4 screws to mount the BL-600 unit.

• When bracket A is used



• When bracket B is used

